


GENERAC[®]
POWER SYSTEMS, INC.

V-Twin

(16 & 18 hp)

ENGINE P/N's 85109, 85110, 92134, 93571



Parts Manual

TABLE OF CONTENTS

16hp V-Twin Prts Beakdown.....Page 2-12
18hp V-Twin Parts Breakdown.....Page 3-23

NOTE: *This manual is divided into two sections, part one pertaining to the 16 horsepower engines, and part two pertaining to the 18 horsepower engines. Each section begins with an illustrated parts breakdown, followed by a repair parts listing. Each repair parts listing covers both the manual and electric start versions of each engine. If a part is used on a specific engine, the engine part number will appear in the "Engine" column. If a part is common to both styles of engine, the word "Both" will appear in the "Engine" column.*





The part numbers for the engines covered in this manual are as follows:






*#85109 16 HP Manual Start
#85110 16 HP Electric Start
#92134 18 HP Manual Start
#93571 18 HP Electric Start*

Please refer to repair manual #81134 for technical information concerning these engines.


Replacement parts should be ordered through your regular source of supply. Please have part numbers available for ease of ordering.

16hp V-Twin










16hp V-Twin



16hp V-Twin





16hp V-Twin

ITEM	ENGINE	GENERAC#	NOTE	DESCRIPTION
1	Both	69376		Cylinder Assembly
2	Both	100-85110		Bushing, Cylinder
3	Both	67805	*	Seal, Oil
5	Both	101-85110		Head, Cylinder #1
5A	Both	102-85110		Head, Cylinder #2
7	Both	103-85110	*+	Gasket, Cilinder Head
8	Both	104-85110		Breather Assembly
9	Both	72315	*	Gasket, Breather (incl. #722)
10	Both	105-85110		Screw, Shoulder
11	Both	70596		Tube, Breather
12	Both	69336	*	Gasket, Crankcase
13	Both	69325		Screw, Hex
15	Both	67888		Plug, Oil Drain
16	Both	100-85109		Crankshaft (incl. timing gear and key, and thrust washers).
	Both	106-85110		Timing Gear Key (incl w/ crankshaft).
	Both	107-85110		Thrust Washers (incl. w/ crankshaft).
17	Both	108-85110		Bearing, Ball
18	Both	70540		Cover, Crankcase
20	Both	67924	*	Seal, Oil
22	Both	109-85110		Screw, Hex
23	85110	110-85110		Flywheel (electric start)
23	85109	101-85109		Flywheel (manual start)
24	Both	112-85110		Key, Flywheel
25	Both	75248		Piston Assy, (std)
	Both	113-85110		Piston Assy, (.010 o/s)
	Both	114-85110		Piston Assy, (.020 o/s)
	Both	115-85110		Piston Assy, (.030 o/s)
26	Both	75249		Ring Set (std)
	Both	116-85110		Ring Set, (.010 o/s)
	Both	117-85110		Ring Set, (.020 o/s)
	Both	118-85110		Ring Set, (.030 o/s)
27	Both	69327		Lock, Piston Pin
28	Both	75250		Pin, Piston
29	Both	119-85110		Rod, Connecting (Std)
	Both	120-85110		Rod, Connecting (.020 o/s)
32	Both	72346		Screw, Hex
33	Both	69316		Valve, Exhaust
34	Both	69317		Valve, Intake
35	Both	121-85110		Spring, Valve
37	Both	102-85109		Guard, Flywheel
39	Both	123-85110		Deflector, Oil
40	Both	69320		Retainer, Valve
42	Both	70513		Keeper, Valve
45	Both	124-85110		Tappet, Valve
46	Both	70530		Gear, Cam

16hp V-Twin

ITEM	ENGINE	GENERAC#	NOTE	DESCRIPTION
50	Both	125-85110		Manifold, Intake
50A	85109	103-85109		Manifold, Exhaust (man. start)
50B	85110	69370		Manifold, Exhaust (elec. start)
51	Both	127-85110	*	Gasket, Intake
52	Both	67895	*+	Gasket, Intake
53	Both	128-85110		Screw, Hex
54	Both	67158		Screw, Hex
55	Both	129-85110		Housing, Rewind Starter
56	Both	130-85110		Pulley, Starter
57	Both	131-85110		Spring, Rewind Starter
58	Both	132-85110		Rope, Starter
59	Both	133-85110		Insert, Grip
60	Both	134-85110		Grip, Starter Rope
84	Both	135-85110		Plug, Pipe
87	Both	68554	*	Seal, Governor Shaft
91	Both	136-85110		Body Assy, Upper
94	Both	137-85110	@	Valve, Idle Adjust
95	Both	138-85110		Screw, Slotted
98	Both	139-85110		Screw, Idle Speed
102	Both	140-85110	@	Gasket, Carb Body
103	Both	79264		Float, Carburetor
104	Both	141-85110	@	Pin, Float Hinge
105	Both	142-85110	@	Valve, Needle
108	Both	143-85110		Valve, Choke
116	Both	70506	*	Seal, O-Ring
116A	Both	68573	*	Seal, O-Ring
116B	Both	70541	*	Seal, O-Ring
117	Both	144-85110	@	Jet, Main (std)
	Both	80883		Jet, Main (High Altitude)
119	Both	145-85110		Screw, Slotted
121	Both	232-85110		Carb Kit
122	Both	70553		Spacer, Carburetor
125	Both	146-85110		Carburetor
127	Both	147-85110	@	Plug, Welch
130	Both	148-85110		Valve, Throttle
131	Both	149-85110		Shaft, Throttle
141	Both	150-85110		Shaft, Choke
142	Both	79277	@	Nozzle, Carburetor
161	Both	86443		Base, Air Cleaner
166	Both	70131		Stud, Hex Drive
166A	Both	151-85110		Stud, Hex Drive
167	Both	75253	*+	Washer
171	Both	67885	+	Nut, Lock
187	Both	AA-47662		Line, Fuel
189	Both	22129		Washer, Lock
192	Both	75254		Screw, Valve Adjust

16hp V-Twin

ITEM	ENGINE	GENERAC#	NOTE	DESCRIPTION
206	Both	152-85110		Nut
207	Both	153-85110		Spring, Control Rod
208	Both	154-85110		Rod, Control
209	Both	155-85110		Spring, Governor
209A	Both	156-85110		Spring, Governed Idle
216	Both	157-85110		Link
216A	Both	158-85110		Rod, Manual Choke
222	Both	159-85110		Bracket, Control
227	Both	72320		Lever, Governor
232	Both	70125		Spring, Link
239	Both	60108		Switch, Oil Pressure
240	Both	160-85110		Filter, Fuel
243	Both	70531		Screen, Oil Pump
271	Both	161-85110		Lever Control
277	Both	67884		Washer
277A	85109	104-85109		Washer
280	85110	163-85110		Bracket, Rod
284	85110	39253		Screw, Hex
300	Both	164-85110		Muffler, Exhaust
304	Both	165-85110		Housing, Blower
305	Both	166-85110		Screw, Hex
305A	Both	66886		Screw, Hex
307	85110	67898		Screw, Hex
307A	85109	105-85109		Screw, Hex
308	Both	168-85110		Cover, Air Guide
308A	Both	169-85110		Cover, Air Guide
309	85110	170-85110		Motor, Starter
310	85110	75256		Screw, Hex
332	Both	171-85110		Nut, Hex
333	Both	67891		Armature, Magneto
334	Both	72356		Screw, Mounting
337	Both	72347		Plug, Spark
346	Both	172-85110		Screw, Hex
351	Both	173-85110		Screw, Hex
353	Both	174-85110		Washer, Lock
353A	Both	175-85110		Washer, Lock
354A	Both	176-85110		Nut, Hex
358	Both	75258		Gasket Set
363	Both	177-85110		Flywheel Puller
383	Both	178-85110		Wrench, Spark Plug
423	Both	66484		Screw, Hex
445	Both	86444		Filter, Air
455	Both	179-85110		Cup, Flywheel
456	Both	180-85110		Plate, Retainer
459	Both	181-85110		Pawl, Starter
461	Both	182-85110		Screw, Retainer

16hp V-Twin

ITEM	ENGINE	GENERAC#	NOTE	DESCRIPTION
467	Both	86445		Knob
503	85110	183-85110		Strap, Starter
510	85110	75260		Drive, Starter
513	85110	75261		Clutch, Drive
515	Both	184-85110		Spring, Pawl
520	Both	185-85110		Terminal
523	Both	70158		Dipstick
524	Both	186-85110	*	Seal, Oil
525	Both	70151		Tube, Oil Filter
526	Both	187-85110		Screw, Phillips Hex
535	Both	188-85110		Filter, Air
537	Both	189-85110	*	Gasket, Air Cleaner
539	Both	190-85110		Clip, Control Rod
544	85110	75269		Armature, Starter
552	Both	72361		Bushing, Governor Crank
552A	Both	72362		Bushing, Governor Crank
562	Both	191-85110		Bolt, Carriage
572	Both	70199		Plate, Breather
573	Both	192-85110		Plate, Back
577	Both	193-85110		Wire Assembly (ign. coil)
592	Both	72321		Nut, Hex
601	Both	70162		Clamp, Hose
608	Both	106-85109		Starter, Rewind
613	Both	69397		Screw, Hex
614	Both	194-85110		Pin, Cotter
615	Both	195-85110		Retainer
616	Both	72367		Crank, Governor
634	Both	72365		Washer
634A	Both	196-85110	@	Collar, Throttle
634B	Both	197-85110	@	Collar, Choke Shaft
635	Both	70562		Boot, Spark Plug
642	Both	86447		Cover, Air Cleaner
643	Both	86448		Retainer, Air Filter
657	Both	67820		Screw, Phillips
688	Both	198-85110		Cap, Spring
718	Both	68555		Dowel, Sleeve
722	Both	sold w/ item #9	*	Seal, O-Ring
726	Both	200-85110		Gear, Ring
727	Both	201-85110		Cover, Starter Drive
729	Both	202-85110		Grommet
729A	Both	203-85110		Clip, Wire
741	Both	204-85110		Gear, Timing
783	85110	75264		Gear, Starter
801	85110	75265		Cap, Drive
802	85110	205-85110		Cap, End
803	85110	206-85110		Housing, Starter


16hp V-Twin

ITEM	ENGINE	GENERAC#	NOTE	DESCRIPTION
819	Both	68572		Screw, Hex
823	Both	70542		Screw, Hex
842	Both	207-85110	*	Seal, Cap
851	Both	75272		Terminal, Cable
862	Both	86449		Strap, Cleaner Mounting
863	85109	107-85109		Bracket, Muffler (man. start)
863A	85110	209-85110		Bracket, Muffler (elec. Start)
866	Both	210-85110		Cover, Air Guide
868	Both	70122		Seal, Valve
871	Both	67813		Bushing
876	85110	211-85110		Kit, Gear
879	Both	212-85110		Cover, Carburetor
883	Both	67897	*+	Gasket, Exhaust
884	Both	213-85110		Clamp, Muffler
896	85110	214-85110		Pin, Roll
915	Both	67195		Liner, Port
978	Both	68548	*	Gasket
982	Both	68527		Screw, Hex
985	Both	215-85110		Insulator
987	Both	216-85110	@	Seal, Shaft
994	Both	217-85110		Arrestor, Spark
1004	Both	218-85110		Duct, Air
1014	Both	86451		Shield, Carburetor
1022	Both	220-85110	*+	Gasket, Rocker Cover
1023	Both	221-85110		Cover, Rocker
1024	Both	70539		Pump, Oil
1025	Both	70536		Spool, Governor
1026	Both	70577		Rod, Push (steel, intake side)
1026	Both	80009		Rod, Push (aluminum, exhaust side)
1027	Both	222-85110		Filter, Oil
1028	Both	223-85110		Adaptor, Filter
1029	Both	224-85110		Arm, Rocker
1030	Both	70567		Shaft, Rocker Arm
1031	Both	70566		Support, Rocker Arm
1033	Both	225-85110		Kit, Valve Overhaul
1046	Both	226-85110		Plug, Blower Housing
1054	Both	227-85110		Tie, Cable
1091	Both	229-85110	@	Cap, Limiter
1100	Both	230-85110		Pivot, Rocker Arm

* Included in Gasket Set # 231-85110






+ Included in Valve Overhaul Kit # 225-85110

@ Included in Carburetor Kit # 232-85110















★ REQUIRES SPECIAL TOOLS TO INSTALL.


PLEASE SEE OWNER'S MANUAL FOR ILLUSTRATION OF OIL FILTER ASSEMBLY ON ELECTRIC START ENGINE #93571









18hp V-Twin





★ REQUIRES SPECIAL TOOLS TO INSTALL.






18hp V-Twin



93571



18hp V-Twin



18hp V-Twin

ITEM	ENGINE	GENERAC#	NOTE	DESCRIPTION
1	Both	100-92134		Cylinder Assembly
2	Both	100-85110		Bushing
3	Both	67805	*	Seal, Oil
5	Both	101-92134		Head, Cylinder #1
5A	Both	102-92134		Head, Cylinder #2
7	Both	103-92134	*+	Gasket, Cylinder Head
8	Both	104-85110		Breather Assembly
9	Both	72315	*	Gasket, Breather (incl. #722)
10	Both	105-85110		Screw, Shoulder
11	Both	70596		Tube, Breather
12	Both	69336	*	Gasket, Crankcase
13	Both	69325		Screw, Hex
15	Both	67888		Plug, Oil Drain
16	Both	104-92134		Crankshaft
	Both	106-85110		Timing Gear Key
	Both	107-85110		Thrust Washer
17	Both	108-85110		Bearing, Ball
18	Both	70540		Cover, Crankcase
20	Both	67924	*	Seal, Oil
22	Both	109-85110		Screw, Hex
23	Both	106-92134		Flywheel
24	Both	112-85110		Key, Flywheel
25	Both	107-92134		Piston Assembly (std)
	Both	108-92134		Piston Assembly (.010 o/s)
	Both	109-92134		Piston Assembly (.020 o/s)
	Both	110-92134		Piston Assembly (.030 o/s)
26	Both	111-92134		Ring Set (std)
	Both	112-92134		Ring Set (.010 o/s)
	Both	113-92134		Ring Set (.020 o/s)
	Both	114-92134		Ring Set (.030 o/s)
27	Both	69327		Lock Pin, Piston
28	Both	115-92134		Pin, Piston
29	Both	119-85110		Rod, Connecting (std)
	Both	120-85110		Rod, Connecting (.020 o/s)
32	Both	72346		Screw, Hex
33	Both	69316		Valve, Exhaust
34	Both	69317		Valve, Intake
35	Both	121-85110		Spring, Valve
37	92134	102-85109		Guard, Flywheel
39	Both	123-85110		Deflector, Oil
40	Both	69320		Retainer, Valve
42	Both	70513		Keeper, Valve
45	Both	124-85110		Tappet, Valve
46	Both	70530		Gear, Cam
50	Both	125-85110		Manifold, Intake
50A	92134	103-85109		Manifold, Exhaust (man. start)

18hp V-Twin

ITEM	ENGINE	GENERAC#	NOTE	DESCRIPTION
50B	93571	69370		Manifold, Exhaust (elec. start)
51	Both	127-85110	*	Gasket, Intake
52	Both	67895	*+	Gasket
53	Both	128-85110		Screw, Hex
54	Both	67158		Screw, Hex
55	Both	129-85110		Housing, Rewind Starter
56	Both	130-85110		Pulley, Rewind Starter
57	Both	131-85110		Spring, Rewind Starter
58	Both	132-85110		Rope, Starter
59	Both	133-85110		Insert, Starter Grip
60	Both	134-85110		Grip, Starter Rope
84	Both	135-85110		Plug, Pipe
87	Both	68554		Seal, Governor Shaft
91	Both	118-92134		Body Assembly, Upper
94	Both	119-92134	@	Valve, Idle Adjustment
95	Both	138-85110		Screw, Slotted
98	Both	139-85110		Screw, Idle Speed
102	Both	140-85110	@	Gasket, Carburetor Body
103	Both	79264		Float, Carburetor
104	Both	141-85110	@	Pin, Float Hinge
105	Both	142-85110	@	Valve, Needle
108	Both	120-92134		Valve, Choke
110	Both	121-92134	@	Washer
116	Both	70506	*	Seal, O-Ring
116A	Both	68573	*	Seal, O-Ring
116B	Both	70541	*	Seal, O-Ring
117	Both	122-92134	@	Jet, Main
119	Both	145-85110		Screw, Slotted
121	Both	123-92134		Carbutetor Kit
122	Both	124-92134		Spacer
125	Both	125-92134		Carburetor
127	Both	147-85110	@	Plug, Welch
130	Both	126-92134		Valve, Throttle
131	Both	127-92134		Shaft, Throttle
141	Both	128-92134		Shaft, Choke
147	Both	129-92134		Jet, Slow Speed
161	Both	86443		Base, Air Cleaner
166	Both	70131		Stud, Hex Drive
166A	92134	151-85110		Stud, Hex Drive
167	Both	75253	*+	Washer
171	Both	67885	+	Nut, Lock
187	Both	AA-47662		Line, Fuel
188	Both	39253		Screw, Hex
189	92134	22129		Washer, Lock
192	Both	75254		Screw, Valve Adjust
201	Both	74946		Link

18hp V-Twin

ITEM	ENGINE	GENERAC#	NOTE	DESCRIPTION
206	Both	152-85110		Nut
207	Both	153-85110		Spring, Control Rod
208	Both	154-85110		Rod Control
209	Both	77348		Spring, Governor
209A	Both	79282		Spring, Governor Idler
216	Both	157-85110		Link
216A	Both	158-85110		Rod, Choke
222	Both	130-92134		Bracket, Control
227	Both	72320		Lever, Governor
232	Both	70125		Spring, Link
239	92134	60108		Switch, Oil Pressure
240	Both	160-85110		Filter, Fuel
243	Both	70531		Screen, Oil Pump
265	Both	131-92134		Clamp, Casing
271	Both	161-85110		Lever, Control
277	Both	67884		Washer
277A	92134	132-92134		Washer
280	Both	163-85110		Bracket, Rod
284	93571	39253		Screw, Hex
300	Both	164-85110		Muffler, Exhaust
304	Both	133-92134		Housing, Blower
305	Both	66886		Screw, Hex
307	Both	67898		Screw, Hex
307A	92134	105-85109		Screw, Hex
308	Both	168-85110		Cover, Air Guide (cyl #1)
308A	Both	169-85110		Cover, Air Guide (cyl #2)
309	93571	170-85110		Motor, Starter
310	93571	75256		Screw, Hex
332	Both	171-85110		Nut, Flywheel
333	Both	67891		Armature, Magneto
334	Both	72356		Screw, Hex
337	Both	72347		Plug, Spark
346	Both	134-92134		Screw, Hex
351	Both	70166		Screw,Phillips Hex
351A	Both	173-85110		Screw, Hex
353	Both	174-85110		Washer, Lock
353A	Both	175-85110		Washer, Lock
354A	Both	176-85110		Nut, Hex
356	Both	193-85110		Wire, Stop
356A	Both	137-92134		Wire, Stop
357	Both	138-92134		Key, Drive Pulley
358	Both	139-92134		Gasket, Set
363	Both	177-85110		Flywheel Puller
383	Both	178-85110		Wrench, Spark Plug
423	Both	66484		Screw, Phillips Hex

18hp V-Twin

ITEM	ENGINE	GENERAC#	NOTE	DESCRIPTION
445	Both	86444		Filter, Air
455	Both	140-92134		Cup, Flywheel
456	Both	180-85110		Retainer
459	Both	181-85110		Dog, Starter
461	Both	182-85110		Screw, Shoulder
467	Both	86445		Knob
478	Both	212-85110		Cover, Carburetor
503	93571	183-85110		Strap, Starter
510	93571	75260		Drive, Starter
513	93571	75261		Clutch, Drive
515	Both	184-85110		Spring, Dog
520	Both	185-85110		Terminal
523	Both	70158		Dipstick
524	Both	67181		Seal, Oil
525	Both	70151		Tube, Oil Fill
526	Both	187-85110		Screw, Phillips Hex
529	Both	143-92134		Extension, Breather
535	Both	188-85110		Filter, Air
537	Both	189-85110	*	Gasket, Air Cleaner
539	Both	190-85110		Clip Rod
544	93571	75269		Armature, Starter
552	Both	72361		Bushing, Crank
552A	Both	72362		Bushing, Crank
562	Both	191-85110		Bolt, Carriage
572	Both	70199		Baffle, Breather
573	Both	192-85110		Plate, Back
592	Both	72321		Nut, Hex
601	Both	70162		Clamp, Hose
608	Both	106-85109		Starter, Rewind
613	Both	69397		Screw, Hex
614	Both	194-85110		Pin, Cotter
615	Both	195-85110		Ring, Retaining
616	Both	72367		Crank, Governor
634	Both	72365		Washer
634A	Both	216-85110	@	Collar, Throttle
634B	Both	197-85110	@	Collar, Choke
634C	Both	145-92134	@	Seal, Shaft
635	Both	70562		Boot, Spark Plug
642	Both	86447		Cover, Air Cleaner
643	Both	86448		Retainer, Air Filter
657	Both	67820		Screw, Phillips
688	Both	198-85110		Cap, Spring
718	Both	68555		Dowel, Crankcase
722	Both	sold w/#9 ONLY		O-Ring
726	Both	200-85110		Gear, Ring
727	93571	201-85110		Cover, Starter Drive

18hp V-Twin

ITEM	ENGINE	GENERAC#	NOTE	DESCRIPTION
729A	Both	202-85110		Clip, Wire
729B	Both	203-85110		Clip, Wire
741	Both	204-85110		Gear, Timing
783	Both	75264		Gear, Starter
801	93571	75265		Cap, Drive
802	93571	205-85110		Cap, End
803	93571	206-85110		Housing, Starter
819	Both	68572		Screw, Hex
823	Both	70542		Screw, Hex
842	Both	207-85110		Seal, O-Ring
851	Both	75272		Terminal, Cable
862	Both	86449		Strap, Air Cleaner Mounting
863	92134	107-85109		Bracket, Muffler (man. start)
863A	93571	209-85110		Bracket, Muffler (elec. start)
866	Both	210-85110		Cover, Air Guide
868	Both	70122		Seal, Valve Guide
871	Both	67813		Bushing, Guide
876	93571	211-85110		Kit, Gear
883	Both	67897	*+	Gasket, Echaust
884	Both	213-85110		Clamp
896	93571	214-85110		Pin, Roll
915	Both	67195		Liner, Port
955	Both	147-92134		Plug
978	92134	68548		Gasket, Oil Filter
982	Both	68527		Screw, Hex
985	Both	215-85110		Insulator
994	Both	217-85110		Arrestor, Spark
1004	Both	218-85110		Duct, Air
1005	Both	148-92134		Fan, Flywheel
1006	Both	149-92134		Retainer, Fan
1014	Both	150-92134		Shield, Carburetor
1022	Both	220-85110	*+	Gasket, rocker Cover
1023	Both	69328		Cover, Rocker
1024	Both	70539		Pump, Oil
1025	Both	70536		Spool, Governor
1026	Both	70577		Rod, Push (steel, intake)
1026	Both	80009		Rod, Push (aluminum, exhaust)
1027	92134	222-85110		Filter, Oil
1029	Both	224-85110		Arm, Rocker
1033	Both	101-93571		Kit, Valve Overhaul
1054	Both	227-85110		Tie, Cable
1091	Both	229-85110	@	Cap, Limiter
1100	Both	230-85110		Pivot, Rocker, Arm

18hp V-Twin

- * Included in Gasket Set 139-92134
- + Included in Valve Overhaul Kit 101-93571
- @ Included in Carburetor Kit 123-92134

Ultimate Service Dealers (USD's)

A/C Energy (IL, WI, IN)

3320 Louise Ave
Steger, IL 60475

Parts: 800-800-0822

Ph: 708-758-2007

Fx: 708-758-2031

AAA Generator & Pump, Inc.

2546 Franklin St.
Ft. Myers, FL 33901

Parts: 800-441-0906

Ph: 941-332-1136

Fx: 941-332-8655

Alliance Energy Services

1715 Lake Drive West
Chanhassen, MN 55317

Parts: 888-353-7044

Ph: 952-448-6313

Fx: 952-448-9302

ARRCO Company Services, Inc.

9918 S. Perdue Ave.
Baton Rouge, LA 70814

Parts: 877-706-2722

Ph: 225-275-2722

Fx: 225-275-1198

Billiou's, Inc.

(CA, NV, UT, CO, AZ, ID, OR, WA, AK, HI)
1343 S. Main St.

Porterville, CA 93257

Parts: 800-245-5468 (dlr)

877-245-5468 (end users)

Ph: 559-784-4102

Fx: 559-781-1875

Comet Industrial Products

(KS, MO, NE)
4800 Deramus
Kansas City, MO 64120-1186

Parts: 888-700-4214

Ph: 816-245-5432

Fx: 816-245-5435

Dixie Sales Company, Inc.

P. O. Box 1408
Greensboro, NC 27402-1408

Parts: 800-753-4943

Ph: 336-375-7500

Fx: 800-535-2862 or 336-621-3555

EGN Distributing

(AL, FL - Panhandle)
2805 6th Ave., So.
Birmingham, AL 35233

Parts: 800-824-0139

Ph: 205-581-1335

Fx: 205-581-1337

Energy Systems, Inc.

(CA, NV, UT)
2619 Lycoming St. #100
Stockton, CA 95206

Parts: 800-250-8085

Ph: 209-983-6900

Fx: 209-983-8919

Frontier Equipment, Ltd.

8029 River Way
Delta, BC Canada V4G 1G9

Parts: 877-946-5531

Ph: 604-946-5531

Fx: 604-946-8524

Hunter & Lomison

(PA, NY - west of I-81)
1956 W. Fourth St.

Williamsport, PA 17701

Parts: 800-922-9540

Ph: 570-326-1764

Fx: 570-326-5042

Huntington Power Co.

(ME, VT, NH, Ea. NY, MA, CT, RI, NJ)
8 Algonkin Rd.

Shelton, CT 06484

Parts: 800-473-1408

So. Windsor: 860-289-8790

Ph: 203-929-3203

Fx: 800-473-7817

Indiana Power & Supply

(KY, OH, IN)
1415 Country Club Rd.

Indianapolis, IN 46234

Parts: 800-229-1672

Ph: 317-271-1672

Fx: 317-271-1673

Kelly Gen. & Equip.

(VA, WV, MD, DE)
8421 Westphalia Rd.
Upper Marlboro, MD 20774

Parts: 800-677-3815

Ph: 301-420-3983

Fx: 301-735-4563

M & I Generator Power Systems

292 E. Mallory
Memphis, TN 38109

Parts: 800-336-0779

Ph: 901-775-1204

Fx: 901-775-3952

Marr Brothers

(TX, NM, OK, AR, LA, MS)
423 E. Jefferson

Dallas, TX 75209

Parts: 800-627-7276

Ph: 214-948-7387

Fx: 800-967-1259

National Generator Service

(NC, SC, GA, TN)
7715 Park Place Rd.
York, SC 29745

Parts: 800-843-9103

Ph: 803-684-0085

Fx: 803-684-1228

Piedmont Power Products

5909 Harold Meadow Rd.
Julian, NC 27283

Parts: 800-861-8622

Ph: 336-685-4100

Fx: 336-685-9007

R. B. Grove

(FL, except Panhandle)
261 SW 6th Street

Miami, FL 33130

Parts: 800-281-7545

Ph: 305-854-5420

Fx: 305-854-0532

Rocky Mountain

6301 N. Broadway
Denver, CO 80216

Parts: 800-337-8480

Ph: 303-428-2517

Fax: 303-428-6785

Southwest Products Supply

5143 W. Roosevelt
Phoenix, AZ 85043

Parts: 800-858-0033

Ph: 602-269-3581

Fx: 602-269-8448

T.W. Enterprises

(MT, WY, ID)
2059 N. 9th Rd.
Worden, MT 59088

Parts: 800-955-3795

Ph: 406-245-4600

Fx: 406-245-4333

Total Power

5080 Timberlea Blvd., #25
Mississauga, Ontario

Canada, L4W 4M2

Parts: 888-870-9152

Ph: 905-238-1529

Fx: 905-238-1533

Wolverine Power

11598 E. Lakewood Blvd.
Holland, MI 49424-8619

Parts: 800-485-8068

Ph: 616-820-0503

Fx: 616-820-0506

Zabatt, Inc.

(FL, So. American, PR & Caribbean)
4612 Highway Ave.

Jacksonville, FL 32254

Parts: 800-366-1323

Ph: 904-384-4505

Fx: 904-384-6478



Billiou's (AK, AZ, CA, CO, HI, ID, NV, OR, UT, WA)

1343 South Main Street
Porterville, CA 93257

Parts: (800) 245-5468

Phone: (559) 784-4102

Fax: (559) 781-1875

Canada Power Tech (CENTRAL CANADA)

161 Watline Ave.
Mississauga, Ont.

Canada L4Z 1P1

Parts: (800) 861-9559 (Canada Only)

Phone: (905) 890-6900

Fax: (403) 454-8377

Canada Power Tech (WESTERN CANADA)

101-10411 178 Street
Edmonton, Alberta

Canada T5S 1R5

Parts: (800) 861-9559 (Canada Only)

Phone: (780) 453-5791

Fax: (780) 454-8377

Canada Power Tech (EASTERN CANADA)

226 Migneron St.
Ville St. Laurent, Quebec

Canada H4T 1Y7

Parts: (800) 861-9559 (Canada Only)

Phone: (514) 731-3559

Fax: (514) 731-0064

Central Power Distributors (MN, ND, SD)

1101 Mckinley Street
Anoka, MN 55303

Parts: (800) 364-7938

Phone: (612) 576-0901

Fax: (612) 576-0920

Central Power Distributors (WI, Northern 1/2 of IL, Upper MI)

N90 W14653 Commerce Dr.
Menomonee Falls, WI 53051

Parts: (800) 450-1979

Phone: (414) 250-1977

Fax: (414) 250-1966

Dixie Sales Company (AL, FL, GA, NC, SC, VA, KY)

5920 Summit Ave
Browns Summit, NC 27214 or
P.O. Box 1408

Greensboro, NC 27402

(800) 753-4943

Phone: (336) 375-7500

Fax: (800) 535-2862

Marr Brothers (AR, LA, MS, NM, OK, TX)

423 E. Jefferson
Dallas, TX 75209

(800) 627-7276

Phone: (214) 948-7387

Fax: (800) 967-1259

Medart Engines (MO, IA, Southern 1/2 of IL)

124 Manufacturers Dr.
St. Louis, MO 63010-4727

(800) 888-7181

Phone: (636) 282-2300

Fax: (888) 510-3100

Medart Engines (KS, NE)

2644 S. 96th St.
Edwardsville, KS 66111

(800) 888-7181

Fax: (800) 695-9530

Medart Engines (TN)

4365 Old Lemar
Memphis, TN 38118

(800) 888-7181

Fax: (800) 695-9530

Original Equipment (MT, WY)

905 Second Ave. South
Billings, MT 59103

(800) 332-7158

Phone: (406) 245-3081

Fax: (406) 245-1652

W.J. Connell (CT, DC, DE, IN, MA, MD, ME, MI, NH, NJ, NY, OH, PA, RI, VT, WV)

65 Green St.
Foxboro, MA 02035

(800) 456-5691

Phone: (508) 543-3600

Fax: (508) 543-8394

W.J. Connell (OH)

875 Seville Road
Wadsworth, OH 44281

(800) 448-8219

Phone: (330) 335-1591

Fax: (330) 335-4305